



VW Alltrack driving/fog light mount kit – Installation Instructions. Please note: BEFORE you install, make sure that your light kit mounting bolt fits the hole in this kit. If you have any questions please message me: chris@uniwerksdesign.com

Installation is easy: (and only a 15 minute job!)

1. Remove top cover plate, 2 fasteners (T25).



2. Using a long claw retriever tool, lower the bracket from the inside of the grill.





3. Then pull out through the grill from the outside.



4. While holding the mount, slide collar until the holes line up.

5. Install fastener (T15) and hex nut.



6. (You may want to put a lock washer (not supplied) on the topside to stop the fastener from hitting the lower bodywork under the mount. It just touched on my car.



7. It's ready for your driving/fog light kit!

